

# Marlin End Cap & Rossi R95 PewView Handguard Installation Instructions

For Ranger Point Precision Marlin 1894/1895/End Cap Models and Rossi R95

## IMPORTANT SAFETY INFORMATION

Before beginning installation:

- Ensure the firearm is completely unloaded
- Open the action and visually inspect the chamber
- Verify the magazine tube is empty
- Remove all live ammunition from the workspace
- Wear eye protection

## Tools Required

- Bench block
- Non-marring hammer
- Non-marring punch
- Flathead screwdriver
- 3/32" Allen key
- 5/64" Allen key
- Blue or Purple Loctite
- Inch-pound torque wrench
- 600-grit wet/dry sandpaper
- Light oil

# Torque Specifications

Use a calibrated inch-pound torque wrench whenever possible.

<b>Fastener Type</b>	<b>Torque Spec</b>
RPP Receiver Screws	10 in-lbs
RPP Barrel Band All Screws	6 in-lbs
Factory Tenon Screws	8 in-lbs
Handguard Alignment / Set Screws	Hand Tight Only
Barrel Contact Set Screws	Hand Tight Only

## Thread Locker

Apply Blue (242) or Purple (222) Loctite to all mounting screws unless otherwise specified.

## Important

- Handguard set screws for alignment.
- Set screws should only lightly contact the barrel.
- Overtightening set screws can affect handguard alignment and damage threads.
- Verify handguard alignment before applying final torque.
- Allow the thread locker to cure before firing.

# Included Hardware

Your handguard package includes:

- M-LOK Handguard
- RPP Stainless Steel Tenon
- (2) Tenon Screws
- (4) Alignment Set Screws
- Allen Keys

## Features

- M-LOK slots at 3, 6, and 9 o'clock
- Integrated QD sling sockets
- Threaded 10-32 sling stud mounting point

# Installation Instructions

## Step 1 – Verify Firearm is Unloaded

Before starting:

1. Open the action.
2. Verify the chamber is empty.
3. Verify the magazine tube is empty.
4. Remove all ammunition from the work area.

# DISASSEMBLY

## Step 2 – Remove Factory End Cap

1. Remove the two factory end cap screws.
2. Remove the magazine tube retaining screw.

### WARNING

Magazine tubes are under spring tension.

Maintain control of the end cap and magazine spring during removal.

## Step 3 – Remove Factory Handguard

1. Carefully lift the end cap away from the rifle.
2. Remove the magazine spring.
3. Slide the magazine tube forward.
4. Remove the factory handguard.

### NOTE

Factory handguards are often tightly fitted between the receiver and tenon.

If necessary:

- Use the magazine tube as a gentle pry point.
- Use a plastic or wooden wedge near the tenon area.
- Avoid excessive force that may damage the factory handguard.

## Step 4 – Remove Factory Tenon

Using a bench block and non-marring punch:

1. Support the barrel properly.
2. Drive the factory tenon from the dovetail.
3. Remove the factory tenon.

## Step 5 – Fit RPP Tenon

The supplied RPP tenon is intentionally oversized.

Test fit the tenon into the barrel dovetail.

If necessary:

1. Apply a small amount of oil to 600-grit wet/dry sandpaper.
2. Sand only the flat surface of the tenon.
3. Test fit frequently.

### IMPORTANT

- Remove material slowly.
- Do not use power tools.
- Excessive material removal can permanently damage fitment.
- The tenon should install with moderate force and remain secure.

## Step 6 – Install RPP Tenon

1. Align the RPP tenon with the barrel dovetail.
2. Drive the tenon into place using a non-marring punch.
3. Verify the tenon is centered.

### IMPORTANT

- The tenon should fit snugly without excessive force.
- If desired, the tenon may be secured with Blue Loctite.
- Do not overtighten or deform the tenon during installation.

# HANDGUARD INSTALLATION

## Step 7 – Install Magazine Tube into Handguard

### IMPORTANT

The magazine tube must be installed into the handguard before final assembly.

1. Insert the magazine tube through the handguard.
2. Ensure the magazine tube is oriented correctly.
3. Verify the loading gate relief section is positioned properly.

### NOTE

On 1895 and .444 models with enlarged magazine tubes, the magazine tube and handguard must be assembled together before installation onto the rifle.

## Step 8 – Install Handguard Assembly

1. Slide the handguard and magazine tube assembly onto the rifle.
2. Insert the rear flange into the receiver.
3. Seat the handguard over the RPP tenon.
4. Verify the handguard is fully seated.

If necessary, lightly tap the handguard into place using a non-marring block.

## Step 9 – Install Magazine Tube and End Cap

1. Reinstall the magazine spring.
2. Reinstall the factory end cap.
3. Reinstall the magazine tube retaining screw.
4. Tighten securely.

## **Step 10 – Install Tenon Screws**

1. Install the supplied tenon screws through the handguard.
2. Thread into the RPP tenon.
3. Leave slightly loose for alignment.

### **IMPORTANT**

Do not fully tighten at this stage.

## **Step 11 – Install Alignment Set Screws**

Install all four set screws.

Locations:

- Two front set screws
- Two rear set screws

### **IMPORTANT**

- Apply Blue or Purple Loctite before installation.
- Set screws should only lightly contact the barrel.

## **Step 12 – Center Handguard**

Visually inspect the gap between the handguard and barrel.

Adjust until:

- Both sides appear even.
- The handguard sits parallel to the barrel.
- The magazine tube remains properly aligned.

# PewView Heat Shield and Picatinny Rail

## Step 13 – Install Heat Shield

Orient the heat shield correctly:

- Slotted end faces the muzzle.
- Two threaded holes face the receiver.
- 1. Slide the heat shield onto the top of the handguard.
- 2. Ensure the heat shield is centered on the handguard.
- 3. Install the four supplied heat shield screws.
- 4. Start all screws by hand to prevent cross-threading.

### IMPORTANT

- Do not force the heat shield into position.
- Verify even spacing on both sides before tightening.

## Step 14 – Center Heat Shield

Inspect the muzzle end of the handguard.

Adjust the heat shield until:

- Equal spacing exists on both sides.
- The heat shield is centered over the barrel.

If necessary:

1. Lightly adjust the front alignment set screws.
2. Allow the set screws to lightly contact the barrel.
3. Verify the heat shield remains centered.

### IMPORTANT

Set screws should only lightly contact the barrel.

## **Step 15 – Install Receiver Rail**

1. Remove the factory receiver plug screws.
2. Position the receiver rail on top of the receiver.
3. Align the rear of the rail with the two threaded holes in the heat shield.
4. Install the four receiver mounting screws.
5. Install the two heat shield mounting screws.

### **IMPORTANT**

Leave all six screws loose until alignment is complete.

## **Step 16 – Final Alignment**

1. Verify the rail sits flat against the receiver.
2. Verify the heat shield remains centered.
3. Verify the handguard is centered around the barrel.
4. Allow the rear set screws to lightly contact the barrel.

## **Step 17 – Final Tightening**

Tighten hardware in the following order:

1. Heat shield to handguard screws — Hand Tight
2. Rail to heat shield screws — Hand Tight
3. Receiver rail screws — 10 in-lbs

### **IMPORTANT**

- Apply Blue or Purple Loctite to all receiver rail screws.
- Do not overtighten heat shield or rail attachment screws.
- Verify alignment before final torque.

# Final Inspection

Before use:

- Verify all screws are secure.
- Ensure the handguard is centered.
- Confirm proper magazine tube alignment.
- Cycle the action to verify proper function.
- Confirm no interference between the handguard, barrel, or magazine tube.

Installation is now complete.