

## Ranger Point M-LOK Modstock Install Instructions

1. Be sure the firearm is unloaded
2. Remove the factory buttstock screw with correct driver
3. Slide off factory buttstock (may need a few light taps of a rubber mallet)
4. Install new Ranger Point Precision Modstock
5. Tighten either the factory screw or new RPP Take-Down Screw
6. Adjust comb height by loosening pivot bolts and set screws, rotate for perfect cheek weld, then tighten screws securely.